


*Parts Manual for*

# **SNAPPER**<sup>®</sup>

## **LEAF BLOWER**

### **SERIES 0**




**MODEL**

**SLB552PN**  
**SLB8621C**

**PARTS FOR THIS MACHINE MUST BE ORDERED FROM:**  
1189 Old Schuylkill Road \* P.O. Box 111 \* Parker Ford, PA 19457-0111  
Phone: (610) 495-7181 or (800) 348-1117, Fax: (610) 495-5951

**SNAPPER** • McDonough, GA., 30253 U.S.A.



<u>Item No.</u>	<u>PART NO.</u> <b>SLB552PN</b>	<u>PART NO.</u> <b>SLB862IC</b>	<u>Quantity</u>	<u>Description</u>
1	705-0088	705-0092	1	Lower Handle Bar Assembly
2	703-0108	703-0108	2	Wheel 4.10 x 3.50 x 4
3	090-0457	090-0457	2	Push Nut Cap
4	705-0028-2	705-0028-2	1	Upper Lifting Handle
5	090-0091	090-0091	2	5/16-18 x 1-3/4" HHCS Pltd
6	705-0044	705-0044	2	Washer Handle Bar
7	705-0034	705-0034	1	Upper Handlebar Assembly
8	705-0002	705-0002	1	Grip, Handlebar
9	090-0057	090-0057	1	1/4-20 x 1-1/2" HHCS Pltd
10	703-0422	703-0422	1	Throttle Control
11	090-0031	090-0031	1	1/4-20 Flex Locknut Pltd
12	703-0415		1	5 HP Engine
		030-0172	1	8HP IC Engine
13A	090-0090		2	5/16-18 x 1-1/2" HHCS Pltd
13B		090-0419	4	5/16-18 x 2-3/4" HHCS Pltd
14	703-0424	703-0424	1	1/4" x 1/4" x 2" Lg. Shaft Key
15	705-0095-RD	705-0095-RD	1	Engine Housing
16	090-0408	090-0408	4	5/16-24 x 3/4" HHCS Pltd
17	090-0392	090-0392	4	5/16" Split Lockwasher Pltd
18	705-0084	705-0084	1	Impeller
19	090-0021	090-0021	1	3/8-24 x 1-1/4" HHCS Pltd
20		705-0097-RD	1	Housing Spacer
21	705-0093-RD	705-0093-RD	1	Front Housing
22	090-0067		11	5/16-18 x 5/8" HHCS Pltd
		090-0090	11	5/16-18 x 1-1/2" HHCS Pltd
23	703-0021-A	703-0021-A	1	Impeller Cover
24	705-0100-RD	705-0104-RD	1	Chute Weld Assembly
25	705-0108	705-0110	1	Divertor Weld Assembly
26	090-0225	090-0225	1	3/8" Internal Lockwasher Pltd.
27	701-0185	701-0185	1	Vinyl Grip, Divertor Handle
28	705-0113	705-0113	1	Divertor Clip
29	090-0052	090-0052	1	1/4-20 x 1/2" HHCS Pltd
30	090-0378	090-0378	2	1/4" Split Lockwasher Pltd
31	090-0232	090-0232	1	1/4" Flat Washer Pltd
32	701-0059	701-0059	1	Spring, Divertor
33	090-0480		1	1/4-20 x 5" Lg. Carriage Bolt
		090-0481	1	1/4-20 x 6" Lg. Carriage Bolt
34	705-0098-RD	705-0099-RD	1	Deflector
35	090-0223	090-0223	1	1/4" Internal Lockwasher Pltd
36	705-0049	705-0049	1	Adjustment Knob
37	090-0067	090-0067	6	5/16-18 x 5/8" HHCS Pltd
38	705-0014	705-0014	1	Front Wheel Bracket
39	705-0056-2	705-0056-1	1	Hex Head Shoulder Bolt
40	705-0043		2	Spacer, Wheel
41	703-0025	701-0052	1	Front Wheel
42	090-0042	090-0042	1	3/8-16 Gripco Locknut
43	090-0418	090-0418	25	5/16-18 Whiz Locknut Pltd
44	090-0228	090-0228	1	3/8" Med. Split Lockwasher

When ordering parts always specify the part number, not the item number.

Parts Manual for

# SNAPPER®

## SLB552PN & SLB8621C LEAF BLOWER SERIES 0

### CAUTION

DO NOT REMOVE IMPELLER  
COVER WHILE MACHINE IS  
RUNNING. SEVERE INJURY  
WILL RESULT.

PART NO. 091-0059

### CAUTION

- (1) READ OPERATING INSTRUCTIONS THOROUGHLY BEFORE USING.
- (2) DANGER: Rotating parts. Keep hands, feet, and clothing out of openings at all times and especially while machine is running.
- (3) NEVER operate with the impeller housing cover removed.
- (4) NEVER direct the discharge air stream towards any persons, children, or animals.
- (5) Stop engine and disconnect spark plug wire before attempting to clean the intake screen or discharge chute.
- (6) Do not use this machine for any purpose other than that for which intended.

PART NO. 091-0058

COPYRIGHT © 1999  
SNAPPER INC.  
ALL RIGHTS RESERVED

**SNAPPER**® McDonough, GA., 30253 U.S.A.